



Installation & Operation Manual



MIN 2500TL-XA

MIN 3000 TL-XA

MIN 3600 TL-XA

MIN 4200 TL-XA

MIN 4600 TL-XA

MIN 5000 TL-XA

MIN 6000 TL-XA

1.	Notes on this manual	5
1.1.	Validity	5
1.2.	Target Group.....	5
1.3.	Additional information	5
1.4.	Symbols in this document	5
1.4.1.	Warnings in this document	5
1.4.2.	Markings on this product.....	6
1.5.	Glossary	7
2.	Safety.....	8
2.1.	Intended Use	8
2.2.	Qualification of skilled person	8
2.3.	Safety instruction.....	9
2.4.	Assembly Warnings	9
2.5.	Electrical Connection Warnings.....	9
2.6.	Operation Warnings	10
3.	Product description	11
3.1.	TL-XA Overview.....	11
3.2.	Type label.....	12
3.3.	Size and weight.....	13
3.4.	Storage of Inverter.....	14
3.5.	The advantage of the unit	14
4.	Unpacking and inspection	14
5.	Installation.....	16
5.1.	Safety instructions	16
5.2.	Selecting the installation location	17
5.3.	Mounting the Inverter	19
5.3.1.	Mounting the Inverter with bracket.....	19
5.3.2.	Fixed the inverter on the wall.....	19
6.	Electrical connection	20
6.1.	Safety	20

6.2.	Wiring AC Output.....	21
6.3.	Connecting the second protective conductor	24
6.4.	Connecting the Battery.....	25
6.4.1.	Conditions for the Battery	25
6.4.2.	Connecting the Battery.....	25
6.4.3.	Connecting to Battery Pack	26
6.5.	Connecting signal cable	27
6.6.	Grounding the inverter.....	28
6.7.	Active power control with smart meter , ripple control signal receiver	28
6.8.	Connecting the COM PORT.....	30
6.8.1.	Inverter demand response modes-DRMs(Australia only)	30
6.8.2.	Inverter demand response modes-Power Control Interface(PCI) for EU.....	31
6.9.	Earth Fault Alarm.....	33
7.	Commissioning	33
7.1.	Start the inverter	33
7.1.1.	Touch control.....	33
7.1.2.	Country setting Country/Area and Region setting	34
7.1.3.	Enabling/Disabling Power Quality Response Modes (PQRM)	35
7.1.4.	Check firmware version,Region,Country/Area and Power	35
7.2.	General setting	35
7.2.1.	Set inverter COM address.....	35
7.2.2.	Set inverter date.....	36
7.2.3.	Set inverter time.....	36
7.3.	Advanced setting	37
7.3.1.	Reset Country,Region and Power Quality Response Modes (PQRM)	37
7.3.2.	Export limitation setting	38
7.3.3.	Reset factory.....	39
7.3.4.	Work mode setting	40
7.3.5.	Grid Charge setting.....	41
7.4.	Communication interfaces	42

7.4.1.	SYS COM Port.....	42
7.4.2.	COM Port	42
7.4.3.	USB-A	43
8.	Startup and Shutdown the inverter	43
8.1.	Startup the inverter	43
8.2.	Shutdown the Inverter	43
9.	Maintenance and Cleaning.....	43
9.1.	Checking Heat Dissipation	44
9.2.	Cleaning the Inverter	44
9.3.	Checking the DC Disconnect	44
10.	EU Declaration of Conformity 10.....	44
11.	Trouble shooting 11.....	44
11.1.	Error Messages displayed on OLED	44
11.2.	System fault	45
11.3.	Inverter warning	45
11.4.	Inverter fault.....	46
12.	Manufacturer Warranty 12	46
13.	Decommissioning 13.....	47
13.1.	Dismantling the Inverter.....	47
13.2.	Packing the Inverter.....	47
13.3.	Storing the Inverter	47
13.4.	Disposing of the Inverter	47
14.	Technical Data	47
14.1.	Specification	47
14.2.	BAT &AC connectors info	51
14.3.	Torque	51
14.4.	Accessories	52
15.	Compliance Certificates 15.....	52
16.	Contact 16.....	52

1. Notes on this manual

1.1. Validity

This manual describes the assembly, installation, commissioning and maintenance of the following Growatt Inverter model

MIN 2500 TL-XA
MIN 3000 TL-XA
MIN 3600 TL-XA
MIN 4200 TL-XA
MIN 4600 TL-XA
MIN 5000 TL-XA
MIN 6000 TL-XA

This manual does not cover any details concerning equipment connected to the MIN TL- XA. Information concerning the connected equipment is available from the manufacturer of the equipment.

1.2. Target Group

This manual is for qualified personnel. Qualified personnel have received training and have demonstrated skills and knowledge in the construction and operation of this device. Qualified Personnel are trained to deal with the dangers and hazards involved in installing electric devices.


1.3. Additional information





Find further information on special topics in the download area at www.ginverter.com The manual and other documents must be stored in a convenient place and be available at all times. We assume no liability for any damage caused by failure to observe these instructions. For possible changes in this manual, Shenzhen Growatt New Energy CO.,LTD accepts no responsibilities to inform the users.

1.4. Symbols in this document










1.4.1. Warnings in this document



A warning describes a hazard to equipment or personnel. It calls attention to a procedure or practice, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the Growatt equipment and/or other equipment connected to the Growatt equipment or personal injury.

Symbol	description
	DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

DANGER	
 WARNING	WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION	CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
 NOTICE	NOTICE is used to address practices not related to personal injury.
 Information	Information that you must read and know to ensure optimal operation of the system.

1.4.2. Markings on this product

Symbol	Explanation
	Electrical voltage!
	Risk of fire or explosion !
	Risk of burns
	Wait for 5minutes before engaging in the indicated action.
	Point of connection for grounding protection
	Direct Current (DC)
	Alternating Current (AC)
	The inverter has no transformer.
	Read the manual

	CE mark. The inverter complies with the requirements of the applicable CE guidelines.
	Discard this product according to local regulations.

1.5. Glossary

AC

Abbreviation for "Alternating Current"

BAT

Abbreviation for battery

DC

Abbreviation for "Direct Current"

Energy

Energy is measured in Wh (watt hours), kWh (kilowatt hours) or MWh (megawatt hours).

The energy is the power calculated over time. For example, your inverter operates at a constant power of 4600 W for half an hour and then at a constant power of 2300 W for another half an hour, it has fed 3450Wh of energy into the power distribution grid within that hour.

Power

Power is measured in W (watts), kW (kilowatts) or MW (megawatts). Power is an instantaneous value. It displays the power your inverter is currently feeding into the power distribution grid.

Power rate

Power rate is the ratio of current power feeding into the power distribution grid and the maximum power of the inverter that can feed into the power distribution grid.

Power factor

Power factor is the ratio of true power or watts to apparent power or volt amps. They are identical only when current and voltage are in phase than the power factor is 1.0. The power in an ac circuit is very seldom equal to the direct product of the volts and amperes. In order to find the power of a single phase ac circuit the product of volts and amperes must be multiplied by the power factor.

Wireless communication


The external wireless communication technology is a radio technology that allows the inverter and other communication products to communicate with each other. The external wireless communication does not require line of sight between the devices and it is selective purchasing.

2. Safety

2.1. Intended Use

The unit converts the DC current generated by the photovoltaic (PV) modules to grid-compliant alternating current and performs single-phase feed-in into the electricity grid. MIN 2500TL-XA, MIN 3000TL-XA, MIN 3600TL-XA, MIN 4200TL-XA, MIN 4600TL-XA, MIN 5000TL-XA, MIN 6000TL-XA inverters are built according to all required safety rules. Nevertheless, improper use may cause lethal hazards for the operator or third parties, or may result in damage to the units and other property.

Principle of a battery plant with this MIN TL-XA single-phase inverter



Position	Description
A	Battery matched with XA inverter
B	DC breaker
C	AC coupled Inverter
D	AC load circuit breaker
E	Energy meter
F	Utility grid

The AC coupled inverter may only be operated with a permanent connection to the public power grid. The AC coupled inverter is not intended for mobile use. Any other or additional use is not considered the intended use. The manufacturer/supplier is not liable for damage caused by such unintended use. Damage caused by such unintended use is at the sole risk of the operator.

2.2. Qualification of skilled person

This inverter system operates only when properly connected to the AC distribution network. Before connecting the MIN TL-XA to the power distribution grid, contact the local power distribution grid company. This connection must be made only by qualified technical personnel to connect, and only after receiving appropriate approvals, as required by the local authority having jurisdiction.


2.3. Safety instruction

The MIN TL-XA Inverters is designed and tested according to international safety requirements


(IEC62109-1,CE,VDE-AR-N4105,CEIO-21,VDE0126-1-1, AS4777,ect.) ;


however, certain safety precautions must be observed when installing and operating this inverter. Read and follow all instructions, cautions and warnings in this installation manual. If questions arise, please contact Growatt's technical services at +86 (0)755 2747 1942.

2.4. Assembly Warnings



 WARNING	<ul style="list-style-type: none">➤ Prior to installation, inspect the unit to ensure absence of any transport or handling damage, which could affect insulation integrity or safety clearances; failure to do so could result in safety hazards.➤ Assemble the inverter per the instructions in this manual. Use care when choosing installation location and adhere to specified cooling requirements.➤ Unauthorized removal of necessary protections, improper use, incorrect installation and operation may lead to serious safety and shock hazards and/or equipment damage.➤ In order to minimize the potential of a shock hazard due to hazardous voltages, cover the entire solar array with dark material prior to connecting the array to any equipment.
--	---

2.5. Electrical Connection Warnings

 DANGER	<ul style="list-style-type: none">➤ The components in the inverter are live. Touching live components can result in serious injury or death.• Do not open the inverter except the wire box by qualified persons.• Electrical installation, repairs and conversions may only be carried out by electrically qualified persons.• Do not touch damaged inverters.➤ Danger to life due to high voltages in the inverter.• There is residual voltage in the inverter. The inverter takes 20 minutes to discharge.➤ Persons with limited physical or mental abilities may only work with the Growatt inverter following proper instruction and under constant supervision. Children are forbidden to play with the Growatt inverter. Must keep the Growatt inverter away from children.
---	---


 <p>WARNING</p>	<ul style="list-style-type: none"> ➤ Make all electrical connections (e.g. conductor termination, fuses, PE connection, etc.) in accordance with prevailing regulations. When working with the inverter powered on, adhere to all prevailing safety regulations to minimize risk of accidents. ➤ Systems with inverters typically require additional control (e.g., switches, disconnects) or protective devices (e.g., fusing circuit breakers) depending upon the prevailing safety rules.
--	--

2.6. Operation Warnings

 <p>WARNING</p>	<ul style="list-style-type: none"> ➤ Ensure all connectors are sealed and secure during operation. ➤ Although designed to meet all safety requirements, some parts and surfaces of Inverter are still hot during operation. To reduce the risk of injury, do not touch the heat sink at the back of the Inverter or nearby surfaces while Inverter is operating.
 <p>CAUTION</p>	<ul style="list-style-type: none"> ➤ All operations regarding transport, installation and start-up, including maintenance must be operated by qualified, trained personnel and in compliance with all prevailing codes and regulations. ➤ Anytime the inverter has been disconnected from the power network, use extreme caution as some components can retain charge sufficient to create a shock hazard; to minimize occurrence of such conditions, comply with all corresponding safety symbols and markings present on the unit and in this manual. ➤ In special cases, there may still be interference for the specified application area despite maintaining standardized emission limit values (e.g. when sensitive equipment is located at the setup location or when the setup location is near radio or television receivers). In this case, the operator is obliged to take proper action to rectify the situation. ➤ Do not stay closer than 20 cm to the inverter for any length of time.

3. Product description

3.1. TL-XA Overview





Position	Description	Position	Description
A	Cover	G	DRM PORT
B	LED	H	AC output
C	OLED	I	Ventilation valve
D	Touch button	J	USB port
E	Battery input+	K	SYS COM port
F	Battery input-		

Symbol on the inverter

Symbol	Description	Explanation		
	Touch symbol	Touch button. We can switch the OLED display and set parameter by touching.		
	Inverter status symbol	Inverter status	LED color	LED status
		Standby	Green	0.5S on and 2S off
		Normal	Green	Solid
		Fault	Red	Solid
		Warning	Green	0.5s on, 0.5s off, 0.5s on, 2S off
		programming	Yellow	1s on and 1s off

3.2. Type label

The type labels provide a unique identification of the inverter (The type of product, Device-specific characteristics, Certificates and approvals). The type labels are on the left-hand side of the enclosure.

 AC Coupled Inverter	
Model name	MIN 6000 TL-XA
AC input/output data	
Rated input/output power	5000/6000 W
Rated output apparent power	6000 VA
Nominal voltage	230 a.c.V
Rated input/output current	22.7/27.2 a.c.A
Nominal frequency	50/60 Hz
Power factor range	0.8leading~0.8lagging
Battery data	
Battery voltage range	360-550 d.c.V
Rated charging and discharging current	17 d.c.A
Type of battery	Lithium
Others	
Overvoltage category	BAT:II AC:III Others:I
Safety level	Class I
Ingress protection	IP65
Operation ambient temperature	-25°C - +60°C
Inverter topology	Non-isolated
Certificate number	SAAxxx
 Made in China	


More detail about the type label as the chart below:

Model Name	MIN 2500 TL-XA	MIN 3000 TL-XA	MIN 3600 TL-XA
DC nominal input voltage	400V		
DC input voltage range	360~500V		360~550V
DC Max input/output current	17A		
AC nominal voltage	230V		
AC grid frequency	50/60 Hz		
Max. apparent power	2500VA	3000VA	3600VA
Max AC output current	11.3A	13.6A	16A
Power factor	0.8leading...0.8lagging		
Environmental Protection Rating	IP 65		

Operation Ambient temperature	- 25...+60°C (-13...+ 140°F) with derating above 45°C (113°F)
-------------------------------	---

Model Name	MIN 4200 TL-XA	MIN 4600 TL-XA	MIN 5000 TL-XA	MIN 6000 TL-XA
DC nominal input voltage	400V			
DC input voltage range	360~550V			
DC Max input/output current	17A			
AC nominal voltage	230VAC			
AC grid frequency	50/60 Hz			
Max. apparent power	4200VA	4600VA	5000VA	6000VA
Max AC output current	19A	20.9A	22.7A	27.2A
Power factor	0.8leading...0.8lagging			
Environmental Protection Rating	IP 65			
Operation Ambient temperature	- 25...+60°C (-13...+ 140°F) with derating above 45°C (113°F)			

3.3. Size and weight



Dimensions and weight

Model	Height (H)	Width (W)	Depth (D)	Weight
MIN 2500-6000 TL-XA	350mm 13.8inch	375mm 14.8inch	160mm 6.3inch	9.1kg

3.4. Storage of Inverter

If you want to storage the inverter in your warehouse, you should choose an appropriate location to store the inverter.


- The unit must be stored in original package , and should be stored in a clean and dry place, and be protected from dust and water vapor corrosion.
- The storage temperature should be always between -25 and +60 . And the storage relative humidity can achieve to 100%.
- If there are a batch of inverters need to be stored, the maximum layers for original carton is four.
- After long term storage, local installer or service department of GROWATT should perform a comprehensive test before installation.

3.5. The advantage of the unit

- Max. efficiency of 98.4%
- 40% lighter
- Storage ready
- AC coupled
- Compatible with double-glass bifacial modules

4. Unpacking and inspection




The inverter is thoroughly tested and inspected strictly before delivery. Our inverters leave our factory in proper electrical and mechanical condition. Special packaging ensures safe and careful transportation. However, transport damage may still occur. The shipping company is responsible in such cases. Thoroughly inspect the inverter upon delivery. Immediately notify the responsible shipping company if you discover any damage to the packaging which indicates that the inverter may have been damaged or if you discover any visible damage to the inverter. We will be glad to assist you, if required. When transporting the inverter, the original or equivalent packaging should be used, and the maximum layers for original carton is four, as this ensures safe transport. After opening the package, please check the contents of the box. It should contain the following, Please check all of the accessories carefully in the carton. If anything missing, contact your dealer at once.



Object	Description	Quantity
A	AC coupled Inverter	1
B	Mounting bracket	1
C	Quick Guide	1
D	Monitor(Optional)	1
E	COM PORT Signal connector	1
	SYS COM PORT Signal connector	1
F	Self-tapping screws	3
G	Safety-lock screw	1
H	Plastic expansion pipe	3
I	AC connector	1
J	Uninstall signal or AC connector tool	1
K	Uninstall PV or Battery terminal tool	1

5. Installation

5.1. Safety instructions


	<p>Danger to life due to fire or explosion</p> <ul style="list-style-type: none"> ➤ Despite careful construction, electrical devices can cause fires. ➤ Do not install the inverter on easily flammable materials and where flammable materials are stored.
	<p>Risk of burns due to hot enclosure parts</p> <p>Mount the inverter in such a way that it cannot be touched inadvertently.</p>
	<p>Possible damage to health as a result of the effects of radiation!</p> <ul style="list-style-type: none"> ➤ In special cases, there may still be interference for the specified application area despite maintaining standardized emission limit values (e.g. when sensitive equipment is located at the setup location or when the setup location is near radio or television receivers). In this case, the operator is obliged to take proper action to rectify the situation. ➤ Never install the inverter near the sensitive equipment (e.g. Radios, telephone, television, etc) . ➤ Do not stay closer than 20 cm to the inverter for any length of time unless

- All electrical installations shall be done in accordance with the local and national electrical codes. Do not remove the casing. Inverter contains no user serviceable parts. Refer servicing to qualified service personnel. all wiring and electrical installation should be conducted by a qualified service personnel .
- Carefully remove the unit from its packaging and inspect for external damage. If you find any imperfections, please contact your local dealer.
- Be sure that the inverters connect to the ground in order to protect property and personal safety.
- Both AC and DC voltage sources are terminated inside the Inverter. Please disconnect these circuits before servicing.
- This unit is designed to feed power to the public power grid (utility) only. Do not connect this unit to an AC source or generator. Connecting Inverter to external devices could result in serious damage to your equipment.
- Energy stored in this equipment's DC link capacitors presents a risk of electric shock. Even after the unit is disconnected from the grid and photovoltaic panels, high voltages may still exist inside the Inverter. Do not remove the casing until at least 5 minutes after disconnecting all power sources.
- Although designed to meet all safety requirements, some parts and surfaces of Inverter are still hot during operation. To reduce the risk of injury, do not touch the h

eat sink at the back of the Inverter or nearby surfaces while Inverter is operating.


5.2. Selecting the installation location

- This is guidance for installer to choose a suitable installation location, to avoid potential damages to device and operators.
- The installation location must be suitable for the inverter's weight and dimensions for a long period time.
- Select the installation location so that the status display can be easily viewed.
- Do not install the inverter on structures constructed of flammable or thermolabile materials.
- Never install the inverter in environment of little or no air flow, nor dust environment. That may derate the efficiency of the cooling fan of the inverter.
- The Ingress Protection rate is IP65 which means the inverter can be installed outdoors and indoors.
- The humidity of the installation location should be 0~100% without condensation.
- The installation location must be freely and safely to get at all times.
- Vertically installation and make sure the connection of inverter must be downwards. Never install horizontal and avoids forward and sideways tilt.



- Be sure that the inverter is out of the children's reach.
- Don't put any things on the inverter. Do not cover the inverter.
- Do not install the inverter near television antenna or any other antennas and antenna cables.
- Inverter requires adequate cooling space. Providing better ventilation for the inverter to ensure the heat escape adequately. The ambient temperature should be below 40°C to ensure optimum operation.

- Do not expose the inverter to direct sunlight, as this can cause excessive heating and thus power reduction.
- Observe the Min. clearances to walls, other inverters, or objects as shown below:




Ambient dimensions of **one inverter**


Ambient dimensions of **series inverters**

- There must be sufficient clearance between the individual inverters to ensure that the cooling air of the adjacent inverter is not taken in.
- If necessary, increase the clearance spaces and make sure there is enough fresh air supply to ensure sufficient cooling of the inverters.

The inverter can't install to solarization, drench, fire location. We suggest that the inverters should be installed at the location with some cover or protection.





- Please make sure the inverter is installed at the right place. The inverter can't install close to trunk.



5.3. Mounting the Inverter


5.3.1. Mounting the Inverter with bracket

 DANGER	<p>In order to avoid electrical shock or other injury, inspect existing electronic or plumbing installations before drilling holes.</p>
--	---



Fix the mounting bracket as the figure shows. Do not make the screws to be flush to the wall. Instead, leave 2 to 4mm exposed.

5.3.2. Fixed the inverter on the wall


 WARNING	<p>Falling equipment can cause serious or even fatal injury, never mount the inverter on the bracket unless you are sure that the mounting frame is really firmly mounted on the wall after carefully checking.</p>
---	---

- Rise up the inverter a little higher than the bracket. Considered the weight of them. During the process please maintain the balance of the inverter.

Hang the inverter on the bracket through the match hooks on bracket.



- After confirming the inverter is fixed reliably, fasten one M6 safety-lock sockets head cap screws on the right or left side firmly to prevent the inverter from being lifted off the bracket.





6. Electrical connection

Decisive Voltage Class (DVC) indicated for ports


Port Name	Class
AC Output	C
DC Input	C
COM&SYS COM Port	A
RS485&USB	A

6.1. Safety

	<p>Danger to life due to lethal voltages!</p> <p>High voltages which may cause electric shocks are present in the conductive parts of the inverter. Prior to performing <u>any work on the inverter, disconnect the inverter on the AC</u></p>
--	---

	and DC sides
	<p>Danger of damage to electronic components due to electrostatic discharge.</p> <p>Take appropriate ESD precautions when replacing and installing the inverter.</p>

6.2. Wiring AC Output

	<p>➤ You must install a separate single-phase circuit-breaker or other load disconnection unit for each inverter in order to ensure that the inverter can be safely disconnected under load.</p> <p>NOTE :</p> <p>The inverter has the function of detecting residual current and protecting the inverter against residual current. If an external RCD breaker is mandatory in the country of installation, you must choose a Type A RCD breaker with the rating residual current not less than 300mA.</p>
---	--


You must install a separate single-phase circuit-breaker or other load disconnection unit for each inverter in order to ensure that the inverter can be safely disconnected under load.


We suggest you choose the AC breaker rating current in this table:

MIN 2500TL-XA	16A/230V
MIN 3000TL-XA	16A/230V
MIN 3600TL-XA	20A/230V
MIN 4200TL-XA	25A/230V
MIN 4600TL-XA	25A/230V
MIN 5000TL-XA	32A/230V
MIN 6000TL-XA	32A/230V


The AC wiring step:

1. Uninstall the parts of the AC connection plug from the accessory bag.









2. Insert the stripped and bared cable through pressure screw, seal ring, threaded sleeve in sequence, insert cables into connection terminal according to polarities indicates on it and tighten the screws firmly. Please try to pull out the wire to make sure the it's well connected.




3. Push the threaded sleeve into the socket, Tighten up the cap on the terminal.




4. Finally, Push or screw the threaded sleeve to connection terminal until both are locked tightly on the inverter.



5. To remove the AC connector, press the bayonet out of the slot with a small screwdriver and pull it out, or unscrew the threaded sleeve, then pull it out.






Wire suggestion length

Conductor cross section	Max. cable length		
	MIN 2500 TL-XA	MIN 3000 TL-XA	MIN 3600 TL-XA
4 mm ² 12AWG	48m	40m	33m
5.2 mm ² 10AWG	60m	50m	42m
Conductor cross section	Max. cable length		
	MIN 4200 TL-XA MIN 4600 TL-XA	MIN 5000TL-XA	MIN 6000 TL-XA
5.2 mm ² 10AWG	28m	26m	24m

6.3. Connecting the second protective conductor

In some installation countries, a second protective conductor is required to prevent a touch current in the event of a malfunction in the original protective conductor. For installation countries falling within the scope of validity of the IEC standard 62109, you must install the protective conductor on the AC terminal with a conductor cross-section of at least 10 mm²Cu. Or Install a second protective conductor on the earth terminal with the same cross-section as the original protective conductor on the AC terminal. This prevents touch current if the original protective conductor fails.




6.4. Connecting the Battery



6.4.1. Conditions for the Battery

The MIN TL-XA single-phase inverter has one independent Battery input : BAT+/BAT- connecting to the output of the Battery.

Notice that the connectors are in paired (male and female connectors). The connectors for the Battery and inverters are Helios H4-R/VP-D4 connectors;




6.4.2. Connecting the Battery


 DANGER	<p>Danger to life due to lethal voltages!</p> <p>Before connecting the Battery, ensure that it does not connect any power supply. NEVER connect or disconnect the Battery.</p> <p>Forbidden to reverse the positive and negative poles of the Battery and the inverter.</p>
 WARNING	<p>Improper operation during the wiring process can cause fatal injury to operator or unrecoverable damage to the inverter. Only qualified personnel can perform the wiring work.</p>

Connection of BAT input terminal

Inverter wiring panel



Battery wiring panel



MIN XH series inverters are connected by the following wires. The BAT+/BAT- of the inverter are connected to the BAT+/BAT- of the battery in turn




6.4.3. Connecting to Battery Pack


This series inverter support to connect lithium ion battery pack, the lithium ion battery pack has its own battery management system, the bidirectional DC/DC box connect to battery pack by RS485 or CAN, the XA series inverters connect to DC-DC box by RS485. In addition, XA series inverters also have a pair of signals for waking up the battery.

SYS COM Port Pin Definitions			
NO.	Port	Definition	Pin assignments front view
1	Enable-	Connect Battery signal port negative	
2	Enable+	Connect Battery signal port positive	
7	BAT_B	Connect Batter communication RS485B or CANL	
8	BAT_A	Connect Battery communication RS485A or CANH	

The communication between the inverter and the battery is connected by the following


wires.



 CAUTION	The communication interface RS485 or CAN between the Battery and the lithium ion battery pack is not properly connected or the electrical disconnection will cause the equipment to work abnormally, or even damage the equipment!
--	--


6.5. Connecting signal cable

This series inverter has two 8 Pin signal connectors, one is COM PORT connector, another is SYS COM PORT connector. Signal Cable Ports as follows:




Procedure


Step 1 Insert the stripped and bared cable through pressure screw, seal ring, threaded sleeve in sequence, insert cables into connection terminal according to number indicates on it and tighten the screws firmly. Please try to pull out the wire to make sure the it's well connected.




Step 2 Push the threaded sleeve into the socket, Tighten up the cap on the terminal.




Step 3 Push the threaded sleeve to connection terminal until both are locked tightly on the inverter.



Step 1 Press the fasteners and pull it out from the inverter.



Step 2 Insert the H type tool and pull it out from the socket




6.6. Grounding the inverter

The inverter must be connected to the AC grounding conductor of the power distribution grid via the ground terminal (PE) .

6.7. Active power control with smart meter , ripple control signal receiver

<div data-bbox="288 1832 359 1906" data-label="Image"> </div> <div data-bbox="258 1924 411 1960" data-label="Text"> <p>Information</p> </div>	<p>The position of export limitation Meter must between the Inverter & Load and gird.</p> <p>Multiple inverter combination is not suitable in Australia.</p> <p>The smart meter can be used only up to 2000m altitude.</p>
---	--

This series inverter has integrated generation limitation control and export limitation Functionality. The generation control function is used to control the active or apparent power output levels of an inverter. The export limit control function for an inverter is used to control the generation from an inverter to manage the export power level from an electrical installation to the grid. To use this function, you can connect smart meter. The smart meter model is Eastron SDM120CT-M(40mA). The primary aperture is 10mm, output cable length is 5m. The arrow on the CT must pointing towards the inverter. The detailed information about the Meter, please refer to Annex -Eastron SDM120CT-M(40mA) user manual.



Manufacturer	Eastron
Type	SDM120CT-M(40mA)

General Specifications

Voltage AC (Un)	230V
Voltage Range	176~276V AC
Base Current (Ib)	0.1V AC
Power consumption	<2W/10VA
Frequency	50/ 60Hz(±10%)
AC voltage withstand	4KV for 1 minute
Impulse voltage withstand	6KV-1.2uS waveform
Overcurrent withstand	20Imax for 0.5s
Pulse output 1	1000imp/kWh (default)
Pulse output 2	0.001(default) /0.01/0.1/1 kWh/kVArh (configurable)
Display	LCD with white backlit
Max. Reading	999999kWh

Environment

Operating temperature	-25°C to +55°C
Storage and transportation temperature	-40°C to +70°C
Reference temperature	23°C ± 2°C
Relative humidity	0 to 95%, non-condensing
Altitude	up to 2000m
Warm up time	3s
Installation category	CAT II
Mechanical Environment	M1
Electromagnetic environment	E2

Degree of pollution	2
---------------------	---


Mechanics

Din rail dimensions	18x118x64 (WxHxD) DIN 43880
Mounting	DIN rail 35mm
Ingress protection	IP51 (indoor)
Material	self-extinguishing UL94V-0

The following table describes how we can connect EASTRON meter (SDM120CT(40mA)) to inverter:



Meter NO.	Pin	Description	Meter Connection
1		CT-input	CT-P(White)
2			CT-N(Black or Blue)
3		N-in	Grid N
4		L-in	Grid L
9		RS485B	RS485B2 connect to inverter SYS COM Pin 8
10		RS485A	RS485A2 connect to inverter SYS COM Pin 7

Active power control with a Radio Ripple Control Receiver(RRCR).




6.8. Connecting the COM PORT


This series inverter has a 8 Pin COM PORT, this port has the function fo demand response modes, for Australian mode, we can use the 8 Pin COM PORT as inverter DRED connection, for European modes, we can use the 8 Pin COM PORT as Power Control Interface(PCI).

 Information	DRMS application description Only applicable to AS/NZS4777.2 DRM0, DRM1, DRM2, DRM3, DRM4, DRM5, DRM6, DRM7, DRM8 are available.
 CAUTION	Damage to the inverter due to moisture and dust penetration Make sure the cable gland has been tightened firmly. If the cable gland are not mounted properly, the inverter can be destroyed due to moisture and dust penetration. All the warranty claim will be invalid.

6.8.1. Inverter demand response modes-DRMs(Australia only)


This series inverter has the function of demand response modes, We use 8Pin COM PORT as inverter DRED connection.

	DRMS application description Only applicable to AS/NZS4777.2:2015.
---	---

Information	DRM0-DRM8 are available.
	<p>Damage to the inverter due to moisture and dust penetration</p> <p>Make sure the cable gland has been tightened firmly.</p> <p>If the cable gland are not mounted properly, the inverter can be destroyed due to moisture and dust penetration. All the warranty claim will be invalid.</p>

6.8.1.1. 8Pin socket pin assignment

Pin	Assignment for inverters capable of both charging and discharging
1	+12V
2	GND
3	DRM 1/5
4	DRM 2/6
5	DRM 3/7
6	DRM 4/8
7	RefGen
8	Com/DRM0




6.8.1.2. Method of asserting demand response modes


Mode	Socket Asserted by shorting pins		Requirement
DRM 0	7	8	Operate the disconnection device
DRM 1	3	8	Do not consume power
DRM 2	4	8	Do not consume at more than 50% of rated power
DRM 3	5	8	Do not consume at more than 75% of rated power
DRM 4	6	8	Increase power consumption
DRM 5	3	7	Do not generate power
DRM 6	4	7	Do not generate at more than 50% of rated power
DRM 7	5	7	Do not generate at more than 75% of rated power
DRM 8	6	7	Increase power generation (subject to constraints from other active DRMs)

6.8.2. Inverter demand response modes-Power Control Interface(PCI) for EU

This series inverter has the function of demand response modes, We use 8Pin COM

PORTas Power Control Interface(PCI) for European models.

 <p>WARNING</p>	<p>Excessive voltage can damage the inverter! External voltage of PCI PORT don't over +5V.</p>
---	--



6.8.2.1. The connector pin assignment and function definition

Pin	Description	Connect to RRCR
1	+12V	Not connected
2	GND	
3	Relay contact 1 input	K1 – Relay 1 output
4	Relay contact 2 input	K2 – Relay 1 output
5	Relay contact 3 input	K3 – Relay 1 output
6	Relay contact 4 input	K4 – Relay 1 output
7	GND	Relays common node
8	Not connected	Not connected

6.8.2.2. The inverter is preconfigured to the following RRCR power levels

PCI Connector(SYS COM PORT)				Active power	Cos(φ)
Pin 3	Pin 4	Pin 5	Pin 6		
Short circuit with Pin7					1
	Short circuit with Pin7				1
		Short circuit with Pin7			1

			Short circuit with Pin7		1
--	--	--	----------------------------	--	---




Active power control and reactive power control are enabled separately

6.9. Earth Fault Alarm

The inverter complies with AS/NZS 5033. The installer does not need to perform any additional actions, as this is already set up. When the Earth fault occurs, the Red LED will light up.

The buzzer in the inverter will keep ringing unless the fault condition is cleared (This function is only available for Australia and New Zealand).

7. Commissioning

 DANGE	Do not disconnect the BAT connectors under load.
 WARNING	Improper operation during the wiring process can cause fatal injury to operator or unrecoverable damage to the inverter. Only qualified personnel can perform the wiring work.
 CAUTION	<p>Damage to the inverter due to moisture and dust penetration</p> <ul style="list-style-type: none"> ➤ Make sure the cable gland has been tightened firmly. ➤ If the cable gland are not mounted properly, the inverter can be destroyed due to moisture and dust penetration. All the warranty claim will be invalid.

Requirements:


- ✓ The AC cable is correctly connected.
- ✓ The BAT connectors are correctly connected.
- ✓ The country is set incorrectly.

7.1. Start the inverter


7.1.1. Touch control

Touch	Description
Single touch	Switch display or Number +1
Double touch	Enter or confirm
Three touch	Previous menu
Hold 5s	Confirm Country/Area or recover default value


7.1.2. Country setting Country/Area and Region setting

 Information	Country/Area and Region setting When the inverter start up,we need to select the right country,if we don't select any country, the inverter will run under AS/NZS4777.2 as default for Australia & Region A,or run under VDE0126-1-1 for other region after 30s.
--	---

When inverter powered on, OLED will light automatically. Once the BAT power is sufficient, OLED displays the following:




Press the touch key once a second to scroll through the different Country, showing on the screen will constantly change. For example, if you want to choose Newzealand, press the control key until the OLED display shows “Newzealand” as below:



Press the touch key 5S, the OLED shows Country setting is complete.




When the Country setting is complete, the OLED display shows “Set Region” as below:



We can set Region A,B or C when you choose Australia, but if you choose Newzealand the default Region is NZ.

When Region A is selected, the inverter loads all the Region A values for power quality response modes and grid protection settings.

7.1.3. Enabling/Disabling Power Quality Response Modes (PQRM)

 Information	<p>PQRM setting</p> <ul style="list-style-type: none">➤ When the Region setting is completed, the inverter will operate under default mode different from region.
--	---

MIN TL-XA contains five types Power Quality Response Modes:


Volt-Var, Volt-watt, Fixed PF, Reactive power, Power limit. If you want to change the Power Quality Response Modes please refer to chapter 7.3.1.

7.1.4. Check firmware version, Region, Country/Area and Power

Quality Response Modes

Single touch to switch display


Double touch to enter next stage menu.



7.2. General setting


7.2.1. Set inverter COM address

The default COM address is 1. We can change COM address as described below: Single touch to switch display or make the number + 1. Double touch to confirm the setting. Set inverter COM address as described below:




7.2.2. Set inverter date

Single touch make the number up. Double touch to confirm the setting. Set inverter date as described below:



7.2.3. Set inverter time

Single touch make the number up. Double touch to confirm the setting. Set inverter time as described below:



7.3. Advanced setting


7.3.1. Reset Country,Region and Power Quality Response Modes (PQRM)

Single touch to switch display or make the number +1.


Double touch to confirm you setting.

Input right password,you can change Country/Area,Region and PQRM settings.


Reset Country



Reset Region




Reset PQRM




7.3.2. Export limitation setting


The -XA series inverters can work in anti-backflow mode through external power meter; the user can set the percentage of power allowed to flow backward through the OLED. Single touch to switch display or make the number + 1. Double touch to confirm the setting, as described below:



7.3.3. Reset factory

 <p>information</p>	<p>Perform this operation with caution because all configured parameters except the current date,time, and model parameters will be restored to their factory defaults.</p>
--	---

Single touch to switch display or make the number + 1.Double touch to confirm the setting.




7.3.4. Work mode setting

When the -XA series inverter is used together with the Battery, the inverter has three working modes, Grid priority, Battery priority and Load priority (default is Load priority mode). Users can set the inverter to work in different modes in different time periods through OLED. Single touch to switch display or make the number +1. Double touch to confirm the setting, as described below: (If you want to set more time periods, you can use the Shinebus tool.)



7.3.5. Grid Charge setting

When the –XA series inverter is used together with the Battery, the inverter can absorb the energy from the grid to charge the battery, and the user can enable the grid charging function(default is disable) through the OLED. Single touch to switch display or make the number +1.Double touch to confirm the setting. as described below:



7.4. Communication interfaces

7.4.1. SYS COM Port

The -XA series inverter provides a 8 pin SYS COM Port connector. The SYS COM Port connector signal distribution and function are shown in the following table:



SYS COM Port Pin Definitions

NO	Definition	NO	Definition
1	Enable-: Connect the BAT enable signal port negative	1	RS485A1:Signal for meter
2	Enable+: Connect the BAT enable signal port positive	2	RS485B1:Signal for meter
3	RS485A2:Connect Min ShineBus or third party monitoring equipment	3	BAT-B: Connect the BAT communication RS485B or CANL
4	RS485B2:Connect Min ShineBus or third party monitoring equipment	4	BAT-A: Connect the BAT communication RS485A or CANH

7.4.2. COM Port

The -XA series inverter provides a 8 pin COM Port connector. The COM Port connector signal distribution and function, please refer to section 6.9.


7.4.3. USB-A

USB-A port is mainly for connecting monitor or firmware update:

Through USB connection, we can connect external optional monitor, for example: Shine

WIFI-X, Shine 4G-X, Shine LAN-X, ShineRFStick-X, etc. And also you can quickly update the software by U disk. We can monitor as below:

Make sure the on the front side, then insert the monitor, fasten the screw.




8.Startup and Shutdown the inverter

8.1. Startup the inverter

Connect the AC circuit breaker of the inverter. Then open the DC switch of the lithium battery, the battery will be awakened, and the inverter will start automatically.


8.2. Shutdown the Inverter

 DANGER	Do not disconnect the BAT connectors under load.
--	--

Shut down the inverter step:

1. Disconnect the line circuit breaker from single-phases grid and prevent it from being reactivated.
2. Turn off the DC switch of the BAT.
3. Check the inverter operating status.
4. Waiting until LED, OLED have go out, the inverter is shut down.

9.Maintenance and Cleaning

 WARNING	Prior to removal of any cover for maintenance or repair, turn off the switch on the AC and DC sides
---	---

9.1. Checking Heat Dissipation

If the inverter regularly reduces its output power due to high temperature, please improve the heat dissipation condition. Maybe you need to clean the heat sink.

9.2. Cleaning the Inverter

If the inverter is dirty, turn-off the AC breaker, DC switch and the BAT input switch, waiting the inverter shut down, then clean the enclosure lid, the display, and the LEDs using only a wet cloth. Do not use any cleaning agents (e.g. solvents or abrasives).

9.3. Checking the DC Disconnect

Check for externally visible damage and discoloration of the DC Disconnect and the cables at regular intervals. If there is any visible damage to the DC Disconnect, or visible discoloration or damage to the cables, contact the installer.

10. EU Declaration of Conformity

With the scope of EU directives:

- 2014/35/EU Low Voltage Directive (LVD)
- 2014/30/EU Electromagnetic Compatibility Directive (EMC)
- 2011/65/EU RoHS Directive and its amendment (EU)2015/863

Shenzhen Growatt New Energy Technology Co. Ltd confirms that the Growatt inverters and accessories described in this document are in compliance with the above mentioned EU directives. The entire EU Declaration of Conformity can be found at www.ginverter.com.

11. Trouble shooting

Our quality control program assures that every inverter is manufactured to accurate specifications and is thoroughly tested before leaving our factory. If you have difficulty in the operation of your inverter, please read through the following information to correct the problem.

11.1. Error Messages displayed on OLED

An error message will be displayed on the OLED screen when a fault occurs. The faults consist of system fault and inverter fault.

You may be advised to contact Growatt in some situation, please provide the following information.

Information concerning the inverter:

- Serial number

- Model number
- Error message on OLED
- Short description of the problem
- Grid voltage
- Can you reproduce the failure? If yes, how?
- Has this problem occurred in the past?
- What was the ambient condition when the problem occurred?

11.2. System fault

System fault (system faults are mainly caused by system instead of inverter, please check the items as instructed below before replacing inverter).

Error message	Description	Suggestion
Residual I High Error: 201	Leakage current too high	Restart the invert. If error message still exists, contact Growatt.
AC V Outrange Error: 300	Utility grid voltage is out of permissible range.	1.Please switch off DC switch. 2.Check AC wiring, especially neutral and ground wire. 3.Check grid voltage is complied with local grid standard. Restart inverter, if problem still exist, 4.Contact Growatt.
No AC connection Error: 302	No AC connection	Check AC wiring. Check the status of AC breaker
PE abnormal Error: 303	Voltage of Neutral and PE above 30V.	Check the voltage of Neutral and PE. Check AC wiring. Restart inverter, if error message still exists,contact Manufacturer
AC F Outrange Error: 304	Utility grid frequency out of permissible range.	1.Please switch off DC switch. 2.Check AC wiring, especially neutral and ground wire. 3.Check grid frequency is complied with local grid standard. 4.Restart inverter, if problem still exist, Contact Growatt.
Auto Test Failed Error: 407	Auto test didn't pass.	1.Restart inverter, repeat Auto Test, if problem still exist, contact Growatt.

11.3. Inverter warning

Warning code	Meanings	Suggestion
Warning204	Dryconnect function abnormal	1.After shutdown,Check the dry Dryconnect wiring. 2.If the error message still exists, contact manufacturer.
Warning207	USB over-current	1.Unplug the U disk or monitor.

		2.Re-access U disk or monitor after shutdown. 3.If the error message still exists, contact manufacturer.
Warning 401	Inverter communicates with Meter abnormal	Check if the meter is on. Check the inverter and the meter connection is normal .
Warning404	EEPROM abnormal	Restart the inverter. If the warning still exist, please contact Growatt customer service to replace the M3 board.
Warning405	Firmware version is not consistent	Update the right version firmware

11.4. Inverter fault

Warning code	Meanings	Suggestion
Error: 402	Output High DCI	1.Restart inverter, if problem still exist, Contact Growatt.
Error: 404	Bus sample fault	1.Restart inverter, if problem still exist, Contact Growatt.
Error: 405	Relay fault	1.Restart inverter, if problem still exist, Contact Growatt.
Error: 408	Over Temperature	1.If the ambient temperature of inverter is lower than 60°C, restart inverter, if error message still exists, contact Growatt.
Error: 409	Bus over voltage	1.Restart inverter, if problem still exist, Contact Growatt
Error: 411	DSP communicates with M3 abnormal	1.Restart inverter, if problem still exist, update the DSP&M3 firmware; 2.Change DSP board or M3 board, if problem still exist, contact Growatt.
Error: 414	EEPROM fault.	1.Restart inverter 2.if problem still exist,contact Growatt
Error: 417	The data sampled by the DSP and redundant M3 is not the same.	1.Restart inverter 2.if problem still exist,contact Growatt
Error: 420	GFCI fault.	1.Restart inverter 2.if problem still exist,contact Growatt

12.Manufacturer Warranty 12

Please refer to the warranty card.

13.Decommissioning 13

13.1. Dismantling the Inverter

1. Disconnect the inverter as described in section.
2. Remove all connection cables from the inverter.
3. Screw off all projecting cable glands.
4. Lift the inverter off the bracket and unscrew the bracket screws.



CAUTION

Danger of burn injuries due to hot enclosure parts!

Wait 20 minutes before disassembling until the housing has cooled down.

13.2. Packing the Inverter

If possible, always pack the inverter in its original carton and secure it with tension belts. If it is no longer available, you can also use an equivalent carton. The box must be capable of being closed completely and made to support both the weight and the size of the inverter.

13.3. Storing the Inverter

Store the inverter in a dry place where ambient temperatures are always between -25°C and +60°C.

13.4. Disposing of the Inverter



Do not dispose of faulty inverters or accessories together with household waste. Please accordance with the disposal regulations for electronic waste which apply at the installation site at that time. Ensure that the old unit and, where applicable, any accessories are disposed of in a proper manner.

14.Technical Data

14.1. Specification

Model	MIN	MIN	MIN	MIN
Specifications	2500 TL-XA	3000 TL-XA	3600 TL-XA	4200 TL-XA

DC input quantities				
Nominal DC input voltage	400V			
DC input voltage range	360-550V		360-550V	
DC input current (maximum continuous)	17A			
DC output quantities				
Nominal DC input voltage	400V			
DC input voltage range	360-550V			
DC input current (maximum continuous)	17A			
Battery type	Lithium ion battery			
AC output quantities				
Rated output power	2500W	3000W	3600W	4200W
Rated apparent power	2500VA	3000VA	3600VA	4200VA
Nominal AC voltage	230V			
AC voltage range	160-276V			
Norminal AC grid frequency	50/60Hz			
AC grid frequency range	45-55Hz/55-65Hz			
Rated output current	11.3A	13.6A	16A	19A
Max. output current	11.3A	13.6A	16A	19A
Max. inrush current (Peak value/duration time)	<10A/5ms			
Max. output fault current	62A/20us			
Max.output overload protection	16A	16A	20A	25A
Backfeed current	0A			
Power factor(@nominal power)	>0.99			
Power factor range	0.8leading... 0.8lagging			
THDi	<3%			
AC grid connection type	Single phase(L/N/PE)			
AC overvoltage category	Category III			
AC input quantities				
Nominal AC input voltage	230V			
AC input voltage range	160-276V			
Rated input current	11.3A	13.6A	16A	19A
AC input current(maximum continuous)	11.3A	13.6A	16A	19A
Inrush current	<10A/5ms			
Nominal frequency	50/60Hz			
AC input frequency range	45-55Hz/55-65Hz			
Efficiency				
Max. efficiency	98.2%	98.2%	98.2%	98.4%
Euro-eta	97.1%	97.1%	97.2%	97.2%
Protection devices				

DC reverse-polarity protection	Integrated
DC Surge protection class	Type II
Insulation resistance monitoring	Integrated
AC surge protection class	Type III
AC short-circuit protection	Integrated
Ground fault monitoring	Integrated
Grid monitoring	Integrated
Anti-islanding protection	Integrated(Active Frequency Drift)
Residual-current monitoring unit	Integrated
General data	
Dimensions (W / H / D) in mm	375*350*160
Weight	9.1 kg
Operating temperature range	-25 °C ... +60 °C
Noise emission (typical)	≤25 dB(A)
Altitude	4000m
Internal consumption at night	<5W@storage mode
Topology	Non-isolated
Overvoltage category	AC:III BAT:II Others:I
Cooling	Natural convection
Ingress protection	IP65
Pollution degree outside the enclosure	3
Pollution degree inside the enclosure	2
Relative humidity	0~100%
DC connection	VP-D4
AC connection	AC connector
Interfaces	
Display	OLED+LED
RS485/USB	Integrated
WIFI/GPRS/4G/LAN/ RF	Optional
Warranty:5/10 years	Yes/ Optional

Model Specifications	MIN 4600 TL-XA	MIN 5000 TL-XA	MIN 6000 TL-XA
DC input quantities			
Nominal DC input voltage	400V		
DC input voltage range	360-550V		
DC input current (maximum continuous)	17A		
DC output quantities			
Nominal DC input voltage	400V		
DC input voltage range	360-550V		

DC input current (maximum continuous)	17A		
Battery type	Cobalt Free Lithium Iron Phosphate (LFP)		
AC output quantities			
Rated output power	4600W	5000W	6000W
Rated apparent power	4600VA	5000VA	6000VA
Nominal AC voltage	230V		
AC voltage range	160-276V		
Norminal AC grid frequency	50/60Hz		
AC grid frequency range	45-55Hz/55-65Hz		
Rated output current	20.9A	22.7A	27.2A
Max. output current	20.9A	22.7A	27.2A
Max. inrush current (Peak value/duration time)	<10A/5ms		
Max. output fault current	<62A/20us		
Max.output overload protection	25A	32A	32A
Backfeed current	0A		
Power factor(@nominal power)	>0.99		
Power factor range	0.8leading... 0.8lagging		
THDi	<3%		
AC grid connection type	Single phase(L/N/PE)		
AC overvoltage category	Category III		
AC input quantities			
Nominal AC input voltage	230V		
AC input voltage range	160-276V		
Rated input current	20.9A	22.7A	22.7A
AC input current(maximum continuous)	20.9A	22.7A	22.7A
Inrush current	<10A		
Nominal frequency	50/60Hz		
AC input frequency range	45-55Hz/55-65Hz		
Efficiency			
Max. efficiency	98.4%	98.4%	98.4%
Euro-eta	97.5%	97.5%	97.5%
Protection devices			
DC reverse-polarity protection	Integrated		
DC Surge protection class	Type II		
Insulation resistance monitoring	Integrated		
AC surge protection class	Type III		
AC short-circuit protection	Integrated		
Ground fault monitoring	Integrated		
Grid monitoring	Integrated		
Anti-islanding protection	Integrated(Active Frequency Drift)		

Residual-current monitoring unit	Integrated
General data	
Dimensions (W / H / D) in mm	375*350*160
Weight	10.8 kg
Operating temperature range	-25 °C ... +60 °C
Noise emission (typical)	< 25 dB(A)
Altitude	4000m
Internal consumption at night	<5W@storage mode
Topology	Non-isolated
Overvoltage category	AC:III BAT:II Others:I
Cooling	Natural convection
Ingress protection	IP65
Pollution degree outside the enclosure	3
Pollution degree inside the enclosure	2
Relative humidity	0~100%
DC connection	Helios H4-R/VP-D4
AC connection	AC connector
Interfaces	
Display	OLED+LED
RS485/USB	Integrated
WIFI/GPRS/4G/LAN/ RF	Optional
Warranty:5/10 years	Yes/ Optional

14.2. BAT & AC connectors info

BAT connectors	VP-D4B-CHSM0B/ VP-D4B-CHSF0B	/
AC connector	VPAC06EP-3S(SC)5	EN032-1128-1001 VPAC06EW-3P(SC)

14.3. Torque

Enclosure lid screws	12kgf.cm
AC terminal	6kgf.cm
Signal terminal	4kgf.cm
M6 socket head cap screws for securing the enclosure at the bracket	12kgf.cm
Additional ground screws	12kgf.cm

14.4. Accessories

In the following table you will find the optional accessories for your product. If required, you can order these from GROWATT NEW ENERGY TECHNOLOGY CO.,LTD or your dealer.

Name	Brief description
Shine WIFI-X	WIFI monitor with USB interface
Shine 4G-X	4G monitor with USB interface
Shine RF-X	RF monitor with USB interface
Shine LAN-X	LAN monitor with USB interface
RS485 Meter	External energy meter for inverter
Shine Master	Shine master for inverter

Shipped to a Growatt service centre for repair, or repaired on-site, or exchanged for a replacement device of equivalent value according to model and age.

The warranty shall not cover transportation costs in connection with the return of defective modules. The cost of the installation or reinstallation of the modules shall also be expressly excluded as are all other related logistical and process costs incurred by all parties in relation to this warranty claim.

15.Compliance Certificates 15

Certificates

With the appropriate settings, the unit will comply with the requirements specified in the following standards and directives (dated: May./2021):

Model	Certificates
MIN 2500-6000TL-XA	CE,IEC62109,AS4777.2,CEI0-21,VDE0126-1-1,VRF2019,VDE-AR-N4105,EN50549,IEC62116,IEC61727,G98,G99

16.Contact 16

If you have technical problems about our products, contact the GROWATT Serviceline. We need the following information in order to provide you with the necessary assistance:

- Inverter type
- Serial number of the inverter
- Event number or display message of the inverter
- Optional equipment

GROWATT NEW ENERGY Co.,LTD

- 4-13/F,Building A,Sino-German (Europe) Industrial Park,Hangcheng Ave,Bao'an District,Shenzhen,P.R.China
- www.ginverter.com
- Serviceline
- Tel: + 86 755 2747 1942
- Email: service@ginverter.com